



NOTES:

1. LOCATE MANHOLE COVER ON SIDE OF MANHOLE AS SHOWN ABOVE. SET MANHOLE FRAME IN GROUT.
2. ALL MANHOLES TO BE WATER TIGHT AND TESTED AS PER STD. SPEC. 02660.
3. MANHOLE BASE AND 1ST SECTION OF MANHOLE TO BE FABRICATED AS AN INTEGRAL UNIT.
4. USE 5' DIAMETER OR LARGER MANHOLE FOR PIPE GREATER THAN 18" DIAMETER.
5. USE 4' DIAMETER MANHOLE FOR ALL PIPE UP TO AND INCLUDING 18" DIAMETER.

PRECAST CONCRETE SEWER MANHOLE

N.T.S

03/12

HEBER CITY
STANDARD DRAWING
SEWER-5