



DROP MANHOLE SHALL BE REQUIRED WHEN INVERTS DIFFER BY 24" OR AS APPROVED BY ENGINEER



SECTION A-A

JUNCTION MANHOLE  
N.T.S



SECTION B-B

DROP MANHOLE  
N.T.S

USE 5" DIAMETER MANHOLE OR LARGER FOR ALL PIPE 14" DIAMETER AND LARGER. USE 4" MIN DIAMETER MANHOLE FOR ALL PIPE SMALLER THAN 14" DIAMETER.

JUNCTION & DROP MANHOLES

N.T.S

03/12

HEBER CITY  
STANDARD DRAWING  
SEWER-3