

NOTES:

1. LOCATE MANHOLE COVER ON SIDE OF MANHOLE AS SHOWN ABOVE. SET MANHOLE FRAME IN GROUT.
2. ALL MANHOLES TO BE WATER TIGHT AND TESTED AS PER STD. SPEC. 02660.
3. MANHOLE BASE AND 1ST SECTION OF MANHOLE TO BE FABRICATED AS AN INTEGRAL UNIT.
4. USE 5' DIAMETER OR LARGER MANHOLE FOR PIPES 14" DIAMETER AND LARGER.
5. USE 4' DIAMETER MANHOLE FOR ALL PIPES SMALLER THAN 14" DIAMETER.


PRECAST CONCRETE SEWER MANHOLE

V:\ENGR\Std\Spec\StdSpec 2019\Drawg Files\SEWER-5.dwg - Manhole Precast - 2/06/2019 11:22am. rfunk

HORROCKS
ENGINEERS

728 WEST 100 SOUTH #2
HEBER CITY, UTAH 84032
(435) 654-2226

DATE:	FEBRUARY 2019
SCALE:	N.T.S.
75 NORTH MAIN STREET HEBER CITY, UTAH 84032 (435) 654-0757	



**HEBER CITY
STANDARD DRAWING**

SEWER-5